

## Directions for use

### GETTING STARTED : FITTING THE BATTERIES

**All 4 batteries** should be **new** when you first use your timer and every time you will replace them. Rechargeable batteries are not advised.

1. Remove the screws securing the battery door.
2. Install 4 AA size 1.5 volt batteries (not included).
3. Screw the battery door back on.

### SETTING THE TIMER

1. Select the interval between two chimes of the gong by turning the pointer of the time-setting knob to face the desired number of minutes.
2. Set the volume level on low 🎵 or normal 🎵
3. Press the ON / OFF button ⇨ the working light is on.

Ten seconds after setting the timer, you will hear the first chime of the gong. It will be repeated at the interval you have chosen for up to 90 minutes; then the working light will automatically be switched off to save the batteries.

To switch off the timer at any moment just press the ON / OFF button. Do **not** force the time-setting knob below zero or beyond 20.

**NOTE:** Make sure you adjust the interval when the power is off.