

## Comparison of the Reiki Timer to the Other Gong Timers & the Gong Clock

Timer Model	Delay Time to First Gong	Number of Rings	Gong Plays at:	Available Setting (mins.)*															
				0 sec**	2	2.5	3	4	5	10	15	20	25	30	40	45	50	60	90
<b>Meditation</b>	20 sec.	3	Beginning & End						●	●	●	●	●	●		●		●	
<b>Combi Timer</b> Duration & Interval Timer	15 sec.	3	Beginning & End of Set <u>Duration</u>									●	●	●	●	●	●	●	●
	--	1	Repeats at Set <u>Interval</u> up to Set Duration Time	●	●		●		●	●	●	●		●					
<b>Reiki</b>	10 sec.	1	Beginning & Repeats at Set Interval up to 90 mins.		●	●	●	●	●	●	●	●							
<b>Gong Clock***</b>	N/A	1	Repeats at Set Interval Indefinitely								●			●				●	
	N/A	3	<i>Alarm Setting</i> (repeats until interrupted)																

\* Even though the control dial of the timers turns smoothly, the settings are fixed. Setting the pointer between two numbers will not give a time setting somewhere between the numbers. The setting will be the one nearest to one of the fixed intervals. For example, if set between 5 and 10 minutes, the timer will run for 5 or 10 minutes, whichever it is closest to.

\*\*The "0" second setting on the Combi Timer makes the Timer function strictly as a Duration Timer without Interval gongs.

\*\*\* Gong Clock with Interval Timer chime activated. The colon symbol on the display will blink on and off when this function is activated.

To Print this screen, press Ctrl-P.